



the ORIGINAL all NATURAL™

— Deluxe —

Food Mill

Thank you for purchasing the Granite•Ware® Deluxe Food Mill, you have selected a top-quality item and will enjoy its many healthy home food preparation uses. The food mill is ideal for milling, ricing, pureeing, peeling and seeding blanched fruits and vegetables.

ASSEMBLY INSTRUCTIONS

1. Rest the mill on a flat level surface.
2. Insert one of the three milling discs included (fine, medium or coarse). The discs are slightly curved for better food processing, the center hole of the disc should rise upward – not point downward – make sure the disc is completely seated flat inside the mill. You may have to lift the mill and elevate the disc upward from underneath to center it and make it rest flat.
3. Hold the crank handle with the spring portion pointing down and knob handle pointing up. Insert the bottom tip of the crank handle into the center hole of the milling disc.
4. Rotate the center bar so the side tabs of the bar align with the side slots of the mill body. Press down on one end of the bar so the tab on the end of the bar slides below the side slot of the mill body. Pull the bar upwards to insert the tab into the slot. The tab should snap in place, this will raise the opposite side of the bar. Press down on the raised end of the bar so the tab at the end of the bar goes below the side slot of the mill, gently release the bar and the tab will snap into place inside the slot.
5. With both tabs securely in the side slots, the mill is ready to use.
6. To remove the disc – rest the food mill on flat level surface. Press down on one side of the center bar until the tab slides out of the side slot. Gently rotate the bar to one side and release the bar so the tab does not go back into the slot. Do the same with the other side. Lift crank handle assembly straight up.

OPERATING INSTRUCTIONS

1. With milling disc and crank handle assembly securely in place (see Assembly Instructions), place food mill over a stock pot or mixing bowl. The two hook ends and the long handle act as balancing points to fit a wide variety of pots and bowls.
2. Place the appropriate amount of food into the mill. This will vary by type of food being processed and choice of milling disc being used.
3. Rotate the handle clock-wise (to the right) to mill the food. The special design of the crank assembly blade will push the food over the milling discs.
4. Rotate the handle counter-clock-wise (to the left) a few times to clear food build up on top of the blade – there is no need to scrape the blade. Rotate the handle to the right to begin milling again.

CARE

Dishwasher safe